

## THE SUREFIRE NO-HASSLE GUARANTEE

We'll do what it takes to keep your SureFire gear running smoothly. SureFire warrants that if you—our customer—purchase one of our products, and we determine that it is defective in material and/or workmanship during your lifetime, we will repair or replace it—no hassle! Rechargeable batteries and chargers are warranted for two years from the date of purchase. SureFire hearing-protection products are warranted for 90 days from the date of purchase. Our warranty does not cover consumables or normal wear-and-tear, or damage resulting from abuse, alterations, unauthorized repairs, or use contrary to SureFire's user manuals. To help protect your investment SureFire offers reasonable rates to repair damage to our products not covered by our warranty, such as a core rebuild for a suppressor damaged by improper use. You will be provided with a quote for approval before work begins.

## STANDARD DISCLAIMER

Except as specified above or prohibited by applicable law: all express or implied conditions and warranties, including, without limitation, any implied warranty or condition of merchantability or fitness for a particular purpose, or accuracy of any informational content, are hereby excluded and disclaimed by SureFire; and in no event will SureFire be liable for any special, direct, indirect, consequential, incidental or punitive damages howsoever arising and regardless of the theory of liability, even if advised of the possibility of such damages. Products, prices, availability, specifications, and offers are subject to change or cancellation at any time without notice.

## WARRANTY CLAIMS

For claims, contact Customer Service at 800-828-8809 or 714-545-9444 to obtain a Return Merchandise Authorization number (RMA#). Then package the unit carefully and send to (no CODs):

SureFire, LLC.  
Repairs Department, RMA# \_\_\_\_\_  
17680 Newhope, Suite B  
Fountain Valley, CA 92708

SureFire will pay reasonable shipping costs to return the unit to you.



18300 MT. BALDY CIRCLE  
FOUNTAIN VALLEY, CA 92708-6122  
SUREFIRE.COM


Revision E 8-2016  
71-01-964  
TITAN-A / TITAN-B



## TITAN® / TITAN® PLUS

ULTRA-COMPACT DUAL- & TRIPLE-OUTPUT LED FLASHLIGHTS

TITAN-A  
TITAN-B



Specifications	TITAN (A)	TITAN PLUS (B)
<b>Output*</b> (low / high)	15 / 125 lumens	15 / 75 / 300 lumens
<b>Intensity</b>	450 candela	1,100 candela
<b>Runtime*</b> (low / high)	8.5 / 1 hrs.	7 / 2 / 1 hrs.
<b>Weight</b>	.9 oz. (27 g)	2.0 oz. (58 g)
<b>Length</b>	3.0 in. (7.62 cm)	3.375 in. (8.6 cm)
<b>Bezel Diameter</b>	.58 in. (1.47 cm)	.58 in. (1.47 cm)

All measurements as per ANSI standard.  
\*Using included rechargeable NiMH battery

USER MANUAL

## TITAN® / TITAN® PLUS

### WE BUILD THE BEST FOR THE BEST

This innovative, best-in-class SureFire illumination tool was designed, engineered, and manufactured in America—using the best components sourced worldwide—to provide you with a lifetime of service. Please be sure to review this manual to ensure optimal performance.

### KIT CONTENTS

#### TITAN:

- One AAA NiMH battery (installed)


#### TITAN PLUS:

- One AAA NiMH battery (installed)
- Pocket clip

### LIGHT OPERATION

**TITAN:** With head facing away from you, rotate it counterclockwise to activate the 15-lumen low-output setting. Rotate bezel clockwise to return to "off" and then rotate counterclockwise again, within one second, to activate 125-lumen high-output setting.

**TITAN PLUS:** With head facing away from you, rotate the bezel counterclockwise to activate the 15-lumen low-output setting. Rotate head clockwise to return to "off" and then rotate counterclockwise again, within one second, to activate the 75-lumen medium-output setting. Repeat process a third time, within one second, to activate 300-lumen high-output setting.



### BATTERY INSTALLATION / REPLACEMENT

#### BATTERY INFORMATION & WARNING

Use of substandard batteries can cause injury or property damage. Before replacing batteries, read the enclosed BATTERY INFORMATION/WARNING insert in your original packaging. For additional battery safety, handling, and product information, visit [www.surefire.com/batteries](http://www.surefire.com/batteries).

Titan and Titan Plus flashlights ship with pre-loaded battery. To load or replace battery:

1. Unscrew bezel (head) counterclockwise and remove.
2. Remove old battery and dispose of properly.



3. Insert new or freshly charged NiMH battery—or a new disposable AAA alkaline or AAA lithium battery—with positive (+) terminal oriented toward bezel.
4. Replace bezel by screwing on clockwise until it stops turning. Test by turning on flashlight.

**NOTE:** Titan and Titan Plus are multi-fuel-capable flashlights and can be powered by rechargeable AAA NiMH batteries or disposable AAA alkaline or lithium batteries.


### RECHARGING NiMH BATTERY

Your included Titan's NiMH battery (both models) is rechargeable. To recharge the NiMH battery, follow the directions of your NiMH-specific charger (not included).

**WARNING:** Use only a NiMH-compatible charger to charge NiMH batteries. NEVER attempt to charge disposable AAA alkaline batteries.

#### Pocket Clip Removal (Titan Plus Only)

Remove the rear cap of body by rotating it counterclockwise. Remove O-ring. Slide the pocket off of the light body and store it somewhere safe. Re-install O-ring. Re-install the rear cap by rotating clockwise until secure.



### MAINTENANCE

Use a clean, dry cloth to wipe off body and window. Periodically clean and lubricate threads and O-rings using a thin coat of non-migrating, silicon-based lubricants. Avoid using petroleum-based lubricants that can damage O-rings. For additional tips on maintaining your SureFire illumination tool, visit [www.surefire.com/faqs-maintenance](http://www.surefire.com/faqs-maintenance).

### ACCESSORIES

SureFire makes a full line of accessories for most of its illumination tools. For a complete listing, visit [www.surefire.com/partsaccessories](http://www.surefire.com/partsaccessories).